

Accessories




USB TRIGGER for CASH DRAWER




Accessories


13" Under-counter Mounting Brackets




1 Mark installation holes with a pencil under your counter.




2 Drill 6 holes on each of the marked spots.



3 Mount 2 brackets against bottom surface of counter using 6 screws provided.



4 Remove 4 screws and rubber feet.



5 Slide cash drawer unit into brackets & align the holes.




6 Mount 4 screws & rubber feet back to the cash drawer unit.

Accessories


16" Under-counter Mounting Brackets




1 Mark installation holes with a pencil under your counter.




2 Drill 6 holes on each of the marked spots.



3 Mount 2 brackets against bottom surface of counter using 6 screws provided.



4 Remove 4 screws and rubber feet.



5 Slide cash drawer unit into brackets & align the holes.



6 Mount 4 screws & rubber feet back to the cash drawer unit.